



# Safety Information

---

**Read this manual carefully before use, and retain it for future reference.**

## Usage Restrictions

- This product is for floor cleaning in a home environment only. Do not use it outdoors, on non-floor surfaces, or in a commercial or industrial setting.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The appliance is only to be used with the power supply unit provided with the appliance.
- This appliance contains batteries that are only replaceable by skilled persons.
- Children shall not play with this product. Ensure children and pets are kept at a safe distance from the robot vacuum while it is operating.
- If the power cord is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its service agent.
- Do not use the robot vacuum in an area suspended above ground level without a protective barrier.
- Do not place the robot vacuum upside down. Do not move the robot vacuum by using its LDS laser sensor

---

cover, cover, or bumper as a handle.

- Do not use the robot vacuum at an ambient temperature above 40°C or below 0°C or on a floor with liquids or sticky substances.
- Do not install, charge, or use this robot vacuum outdoors, in bathrooms, or near a pool.
- A hazard may occur if the appliance runs over the supply cord.
- Remove fragile or small items from the floor to prevent the robot vacuum from bumping into and damaging them.
- Keep the cleaning tool out of reach of children.
- Do not place children, pets, or any item on top of the robot vacuum regardless of whether it is stationary or moving.
- Keep hair, fingers, and other body parts away from the suction opening of the robot vacuum.
- Do not use the robot vacuum to clean any burning substances.
- Do not vacuum up hard or sharp objects.
- The plug must be removed from the socket-outlet before cleaning or maintaining the appliance.
- Do not wipe the robot vacuum or charging dock with a wet cloth or rinse them with any liquid. After cleaning washable parts, fully dry the parts before reinstalling and using them.

- 
- Make sure the robot vacuum is turned off when being transported and kept in its original packaging if possible.
  - Please use this product in accordance with the instructions in the user manual. Users are responsible for any loss or damage arising from improper use of this product.

## Batteries and Charging

### WARNINGS:

- Do not use any third-party battery, power cord, or charging dock. The robot vacuum can only be used with the model CDZ2101 charging dock.
- No action needed from users to shift the charging dock between 50 Hz and 60 Hz, and the product can adapt itself for both 50 Hz and 60 Hz.
- Do not dismantle, repair, or modify the battery or charging dock on your own.
- Do not place the charging dock near a heat source.
- Do not use a wet cloth or wet hands to wipe or clean the dock's charging contacts.
- If the robot vacuum will not be used for an extended period, fully charge it, then turn it off and store in a cool, dry place. Recharge the robot vacuum at least once every 3 months to avoid over-discharging the battery.
- The lithium-ion battery pack contains substances that are hazardous to the environment. Before disposing of the robot vacuum, please first remove the battery pack, then discard, or recycle it in

---


accordance with local laws and regulations of the country or region it is used in.

- When removing the batteries from the product, it is better to use up the batteries and make sure your product is disconnected from power.
  - 1). Uninstall the screw on the bottom, then remove the cover.
  - 2). Unplug the battery connector, then remove the batteries. Do not damage the battery case to avoid any risk of injuries.
  - 3). Return the batteries to a professional recycling organization.


#### Laser Safety Information

- This product's laser radar meets the IEC 60825-1:2014 Standard for Class I laser product safety and does not produce laser radiation hazardous to the human body.

#### EU Declaration of Conformity

 Hereby, Dreame (Tianjin) Information Technology Co., Ltd. declares that the radio equipment type B105 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:  
<http://www.mi.com/global/service/support/declaration.html>  
For detailed e-manual, please go to [www.mi.com/global/service/userguide](http://www.mi.com/global/service/userguide)

# Product Overview



Robot Vacuum


**Note:** Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

## Accessories


Pre-installed Accessories




Brush



Brush Cover



Dust Compartment



Water Tank


## Other Accessories




Side Brush



Cleaning Tool




Power Cord



Mop Pad × 2  
(Pre-installed)




Mop Pad Holder × 2



Charging Dock


---

## Robot Vacuum




**Note:** When the robot vacuum is cleaning or returning to the dock to charge, press any button to pause it.

# Robot Vacuum and Sensors







## Charging Dock




## Water Tank



## Dust Compartment




## Mop Assembly



# How to Install


## Remove Protective Coverings

Before using the robot vacuum, remove the protective strips from both sides.




## Install the Side Brush

Install the side brush onto the clip on the bottom of the robot vacuum.



## Connect to An Electrical Outlet


Place the charging dock near an electrical outlet in an area with a good Wi-Fi signal. Then connect the charging dock to power.



**Note:** Do not place any items within the range of 0.5 m at either side or within 1.5 m in front of the charging dock.

## Place the Robot Vacuum

Place the robot vacuum onto the charging dock, and the robot vacuum will automatically turn on and start charging. After 10 minutes of being fully charged, the indicator will go out. Fully charge the robot vacuum when using it for the first time.



**Note:** Make sure the charging contacts on the robot vacuum and the dock are fully aligned.

# How to Use


## Connect with the Mi Home/Xiaomi Home App

This product works with the Mi Home/Xiaomi Home app\*. Use the Mi Home/Xiaomi Home app to control your device, and to interact with other smart home devices.

Scan the QR code to download and install the app. You will be directed to the connection setup page if the app is installed already. Or search for "Mi Home/Xiaomi Home" in the app store to download and install it.



5812D4E4

Open the Mi Home/Xiaomi app, tap  on the upper right, and then follow the instructions to add your device.



\* The app is referred to as Xiaomi Home app in Europe (except for Russia). The name of the app displayed on your device should be taken as the default.

### Notes:



- This robot vacuum works with the Mi Home/Xiaomi Home app, and it supports Android 4.4 & iOS 10.0 or above.
- Only 2.4 GHz Wi-Fi networks are supported.
- The version of the app might have been updated, please follow the instructions based on the current app version.


## Reset Wi-Fi


When there is a connection loss between your phone and the robot vacuum due to the router reconfiguration, wrong password or so, please follow the steps below:

1. Open the cover of the robot vacuum so that you can see the Wi-Fi indicator.
2. Simultaneously press and hold the buttons  and  until you hear a voice to indicate that the robot vacuum is waiting for the network configuration.
3. When the Wi-Fi indicator blinks, the Wi-Fi connection has been reset successfully.


## Start Cleaning

Press the button  on the robot vacuum or tap the button  in the app, and the robot vacuum will clean all areas by first cleaning along edges and walls and then in an S-shape pattern. Once the cleaning is complete, the robot vacuum will automatically return to the charging dock to charge.

Method 1: Press the button  on the robot vacuum to start cleaning.



Method 2: Tap the button  in the app to start cleaning.




### Notes:


- Before a cleaning task, make sure the robot vacuum is on the charging dock and fully charged.
- Do not move the robot vacuum during cleaning.
- When using the robot vacuum for the first time, it is recommended to follow the robot vacuum and remove any obstacles on the ground. If the robot vacuum may get stuck or scratch the surface of the furniture in some areas, you can set restricted areas in the app to prevent the robot vacuum from entering those areas.

## Use the Vacuuming & Mopping Function

1. First dampen the mop pad and wring out excess water.  
Next, install and attach the mop pad onto the mop pad holder in place.  
Lastly, install the mop assembly onto the bottom of the robot vacuum.





2. Open the cover of the robot vacuum and take the water tank out. Fill the water tank with tap water and then reinstall the tank.




### CAUTIONS:

- Do not add hot water to the water tank, as this may cause the tank to become deformed.
- To avoid clogging, do not add any cleaning agents or disinfectants to the water tank.

3. Press the button  on the robot vacuum or use the app to make the robot vacuum perform the vacuuming and mopping task.



4. When the robot vacuum finishes a task and returns to the charging dock, remove the mop assembly and wash the mop pads in time.





**Note:** If the robot vacuum will not be used for an extended period, remove the water tank and empty it to prevent odor and mildew.

---

## Resume Cleanup

If the robot vacuum starts running low on battery during a cleaning task, it will automatically return to the charging dock to recharge, then resume cleanup where it left off after being charged sufficiently.

## Pause

While the robot vacuum is running, press any button on the robot vacuum to pause it, and then press the button  to resume the cleaning. Pressing the button  will end the current cleaning task and send the robot vacuum back to the charging dock.

**Note:** Do not pick up or move the robot vacuum while it is paused, so as to avoid navigation errors that could prevent the robot vacuum from returning to the charging dock or cause the loss of map.

## Sleep Mode



The robot vacuum will automatically enter sleep mode after it is paused for 10 minutes, and its indicator will go out. To wake it up, press any button on the robot vacuum.

**Note:** If the sleep time exceeds 12 hours, the robot vacuum will be turned off automatically.

## Update the Firmware


You can update the firmware via the app. Before updating, make sure the robot vacuum is on the charging dock and has at least 15% battery left.

## Restart the Robot Vacuum

If the robot vacuum stops responding or cannot be turned off, press and hold the button  for 15 seconds to forcefully turn it off. Then press and hold the button  for 3 seconds to turn the robot vacuum on.

## Restore Factory Settings

If the robot vacuum does not function properly after being restarted, you can use a pin to press the reset button until you hear a voice to indicate that the robot vacuum is restoring factory settings. This will reset the robot vacuum to its original factory settings.




# Care & Maintenance

## Sensors and Charging Contacts\* It is recommended to clean every month.

Use a soft cloth to clean all sensors and charging contacts in the robot vacuum:



- The cliff sensors and the charging contacts at the bottom of the robot vacuum.
- The LDS laser sensor on the top of the robot vacuum.
- The bumper and the line laser sensors on the front of the robot vacuum.



## Brush\* It is recommended to clean every two weeks.

1. Flip the robot vacuum over and pinch the clips to remove the brush cover.
2. Lift the brush out of the robot vacuum, then clean the brush bearings.
3. Use the included cleaning tool to cut any tangled hairs on the brush, and remove the hairs and other debris from the brush.
4. Reinstall the brush and the brush cover, and ensure they are securely in place.


**Note:** It is recommended to replace the brush every 6–12 months for optimal cleaning performance.



**CAUTION:** If too much hair is tangled in the brush, or if the hair is tightly tangled, do not forcibly pull on it to avoid damaging the brush.

## Side Brush\* It is recommended to clean every two weeks.


1. Flip the robot vacuum over and remove the side brush upwards to clean it.
2. Reinstall the side brush to the robot vacuum.



**Note:** It is recommended to replace the side brush every 3–6 months for optimal cleaning performance.

## Omnidirectional Wheel\* Clean it as needed.

1. Flip the robot vacuum over and pull out the omnidirectional wheel.
2. Remove hair, dirt, and other debris from the wheel and axle.
3. Reinsert the wheel and press it firmly back into place.




### Notes:


- A small screwdriver or other pry tool can be used to gently pop out and remove the wheel.
- The wheel can be cleaned with water and reinstalled after drying.

## Dust Compartment\* It is recommended to clean every week.

1. Open the cover of the robot vacuum, and press the dust compartment clip to remove the dust compartment upwards.



2. Open the dust compartment cover, and empty out the contents.




**Note:** To prevent the filter from becoming clogged, lightly tap the dust compartment when emptying its contents.


---

**Filter\*** It is recommended to clean every two weeks.

1. Remove the filter from the filter clip as illustrated.




2. Rinse and gently tap the edges of the filter to remove any dust and debris until it is clean.




**Note:** Do not attempt to clean the filter with a brush or finger.

3. Open the dust compartment cover, fill the dust compartment with clean water and close the dust compartment cover. Shake the dust compartment from side to side and then pour the dirty water out of the compartment.



**CAUTION:** Only use clean water to clean the filter. Do not use detergent.

4. Place the dust compartment and filter aside to dry before reinstallation.




**Note:** Thoroughly dry the dust compartment and the filter before putting them back.




## Mop Pad\* After-each-use cleaning is recommended.

1. Remove the mop pad from its holder.




2. Clean and dry the mop pad.



**Note:** It is recommended to replace the mop pad every 3–6 months for optimal cleaning performance.

## Charging Dock\* Clean it as needed.

Clean the charging contacts and the signaling area of the charging dock with a soft, dry cloth.



## Battery

The robot vacuum contains a high-performance lithium-ion battery pack. Please ensure that it remains well-charged during daily use to maintain optimal battery performance.

**Note:** If the robot vacuum is not used for an extended period, turn it off and put it away. To prevent damage from over-discharging, the robot vacuum should be recharged at least once every three months.

# Troubleshooting

---

Issue	Possible Cause and Solution
The robot vacuum does not turn on.	The battery level is low. Fully charge the robot vacuum, and then try again. The ambient temperature is lower than 0°C or higher than 40°C. Make sure to use the robot vacuum between 0°C and 40°C.
The robot vacuum does not charge.	Check whether the power cord is properly plugged into both the charging dock and the power outlet, and make sure the charging contacts are clean. If not, please wipe the charging contacts on both the dock and the robot vacuum clean with a dry cloth.
The robot vacuum cannot return to the dock to charge.	Check whether there are too many obstacles around the charging dock, place the dock in a location without any obstacles around it. Make sure there are no obstacles within 0.5 meters on both sides, nor within 1.5 meters in front of the charging dock. Please clean the dock's signaling area.
The robot vacuum does not work as expected.	Turn off the robot vacuum, and turn it on again.
The robot vacuum makes a strange noise.	A foreign object might be caught in the brush, side brush, or one of the main wheels. Stop the robot vacuum and remove any debris.
The robot vacuum does not clean as efficiently as before, or leave dust behind.	Please check whether the dust compartment is full. If so, empty it. Furthermore, please check the filter and clean it if necessary, and also check whether there is anything wrapped around any of the brushes.
Network configuration fails.	The Wi-Fi password is incorrect. Make sure the password entered is correct. Switch to a 2.4 GHz network, as 5 GHz networks and enterprise routers are not supported currently. Make sure the robot vacuum stays within an area with a good Wi-Fi signal. The robot vacuum may not be in the awaiting connection state. Exit and reopen the app, and follow the correct steps to try configuring the network again.

---

Issue	Possible Cause and Solution
The robot vacuum does not carry out the scheduled cleanup.	Check whether the battery level is sufficient. The robot vacuum needs to have a battery level of 15% or more to start a scheduled cleanup.
The mop pad is not wet enough.	Check whether the water in the water tank is sufficient. Dampen the mop pad and wring out excess water before mopping. Follow the instructions in the user manual to install the mop pads correctly.
The mop pad is too wet.	Dampen the mop pad and make sure to wring out excess water. Make sure the plug of the water tank is tightened properly.
The robot vacuum consumes electricity when it is left at the dock after being fully charged.	When the robot vacuum is left at the dock, it will consume a small amount of electricity to allow the battery to maintain optimal performance in sleep mode.
The robot vacuum does not resume cleaning after charging.	The robot vacuum does not resume cleaning in do not disturb (DND) mode, or after manually being returned to the dock to charge.
The robot vacuum does not return to the charging dock after being moved.	Moving the robot vacuum may cause it to re-position itself or re-map its surroundings. If the robot vacuum is too far from the charging dock, it might not be able to automatically return on its own, in which case you need to manually place the robot vacuum onto the charging dock.
The mop pad cannot rotate.	The mop pad may be stuck by a foreign object. Please remove the foreign object then try again.

# Specifications

## Robot Vacuum

Name	Robotic Vacuum Cleaner
Model	B105
Item Dimensions	350 × 350 × 97 mm
Battery	4800 mAh (Rated Capacity)
Charging Time	Approx. 6 hours
Net Weight (Robot Vacuum)	3.8 kg
Net Weight (with Accessories)	4.6 kg
Compatible with	Android 4.4 & iOS 10.0 or above
Wireless Connectivity	Wi-Fi IEEE 802.11 b/g/n 2.4 GHz, Bluetooth 4.2
Rated Voltage	14.4 V ---
Rated Power	55 W
Operation Frequency	2400–2483.5 MHz
Maximum Output Power	< 20 dBm

## Charging Dock

Model	CDZ2101
Item Dimensions	130 × 126 × 93 mm
Rated Input	100–240 V ~ 50/60 Hz 0.5 A
Rated Output	19.8 V --- 1 A

Under normal use of condition, this equipment should be kept a separation distance of at least 20 cm between the antenna and the body of the user.

## WEEE Disposal and Recycling Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.

- For further information, please go to [www.mi.com](http://www.mi.com)
- Manufactured for: Xiaomi Communications Co., Ltd.
- Manufactured by: Dreame (Tianjin) Information Technology Co., Ltd. (a Mi Ecosystem company)  
Address: Room 2112-1-1, South District, Finance and Trade Center, No.6975 Yazhou Road, Dongjiang Bonded Port Area, Tianjin Pilot Free Trade Zone, 300463 Tianjin, China

Importer:  
Beryko s.r.o.  
Pod Vinicemi 931/2, 301 00 Plzeň  
[www.beryko.cz](http://www.beryko.cz)

Made in China

