



Mi True Wireless Earphones 2S

User Manual



Read this manual carefully before use, and retain it for future reference.

Product Overview



Illustrations of product, accessories, and user interface in the user manual are for reference purposes only. Actual product and functions may vary due to product enhancements.

Instructions

Charging

● Charging the earphones

When the earphones are placed in the charging case, they will automatically start charging.

● Charging the charging case

Use a Type-C charger to charge the charging case, or place the charging box light up on a compatible wireless charger. The red indicator light flashes during charging, and the white indicator light turns off after charging for 10 seconds.

Note: Prior to first use, the earphones are deactivated. To activate them, place them into the charging case, and press the function button for 5 seconds. We recommend fully charging the earphones before using them for the first time.

Checking Battery Level

● Checking the battery level of the earphones

After connecting the earphones to a phone, you can check the earphones' battery level on the phone's status bar.

Note: The phone's status bar always displays the battery level of the earphone with the lowest battery level. This feature is not supported

by some phones.

● Checking the battery level of the charging case

Open the charging case's lid, or press the function button if the lid is closed:

- ① When the indicator light of the charging case stays lit for 5 seconds, it means the battery is sufficient.
- ② When the charging case's indicator light is blinking, it means the battery level is low and should be charged immediately.

● Checking the battery level by a Mi phone

After successfully connecting to a phone, place the earphones into the charging case and close its lid. Make sure the Bluetooth function is enabled on your Mi phone. Hold your phone close to the charging case, then open the case's lid. A notification will appear on the phone, then you can check the battery level of the earphones and the charging case.

Note: When checking the battery level on your phone, please update your Mi phone to the latest stable version. This feature is currently only supported by some Mi phones.

Turning On

When opening the charging case, the earphones will automatically turn on.

Sleep Mode

Place the earphones back into the charging case and close the lid, the earphones will disconnect and go into sleep mode automatically.

Wearing

Take the earphones out of the charging case, and insert them into your ears according to the left (L) and right (R) marks.

Note: After using the earphones, place them back into the charging case. This will extend their lifespan and help you avoid losing or misplacing them.

Connecting

Connecting the earphones to a new device

- ① Place the earphones into the charging case, then press and hold the function button for 2 seconds. The charging case indicator light will start blinking, indicating that the earphones are waiting to be connected.
- ② Enable the device's Bluetooth, then locate and connect to "Mi TW Earphones 2S". If a passcode is requested, enter "0000".

● Connecting the earphones with a Mi phone

Place the earphones into the charging case and close its lid. Make sure the Bluetooth function is enabled on your Mi phone. Hold your

phone close to the charging case, then open the case's lid. Follow the on-screen instructions of the phone to connect to the earphones.

Note: The feature of fast connection is currently only supported by some Mi phones, please update your Mi phone to the latest stable version.

● Connection interrupted

When a device's Bluetooth is disabled, or if the earphones are out of range, the earphones will automatically enter awaiting connection mode. If the earphones remain disconnected to a device for 5 minutes, they will enter sleep mode. Wearing the earphones again will wake them up and enter awaiting connection mode.

● Automatic connection

While the earphones are in the charging case, opening the case will cause the earphones to automatically connect to the most recently used Bluetooth device. If no connection history is detected, or if the earphones cannot successfully connect to any Bluetooth device, the earphones will automatically enter the awaiting connection mode.


Note: If the earphones cannot automatically connect to a device, you will need to manually connect the earphones to the desired device via the device's Bluetooth settings.

Due to the connection characteristics of the Bluetooth signal, in dense environments with 2.4 GHz electromagnetic signal interferences, there may be occasional disconnects or no sound.

Clearing connection history

- ① Place the earphones into the charging case.
- ② Press and hold the function button on the charging case for more than 10 seconds. Once the indicator alternately blinks red and white, release the button.
- ③ The connection history has been cleared and the indicator of the charging case blinks white. Then the earphones are awaiting for a pairing.

Function Overview



- Incoming calls
Gently tap either one of the earphones twice: Answer/End calls
- Music and voice assistant
While wearing both earphones:
Gently tap the right (R) earphone twice: Play/Pause music
Gently tap the left (L) earphone twice: Access the voice assistant
Taking out an earphone: Pause music
While wearing one earphone:
Gently tap the earphone twice: Play/Pause music

Notes:

- ① The voice assistant function can be used only if your device supports it, and this function needs to be granted permission on the device.
- ② When only using the left earphone, place the right earphone into the charging case and close the lid.

Specifications

Model: TWSEJ07WM Net Weight: 52 g Input: 5 V $\overline{=}$ 1 A
Charging Port: Type-C Impedance: 32 Ω Charging Time: Approx. 1 h

Wireless Connectivity: Bluetooth 5.0

Bluetooth Profiles: BLE/HFP/HSP/A2DP/AVRCP

Supported Audio Codecs: SBC/AAC/LHDC

Wireless Range: 10 m (open space without obstacles)

Earphones' Battery Life (standalone): Approx. 5 h

Total Battery Life (with charging case): Approx. 24 h

Bluetooth Operation Frequency: 2402–2480 MHz (for EU)

Maximum Transmit Power for BT: 10 dBm (for EU)

Maximum Transmit Power for BLE: 10 dBm (for EU)

WEEE Information



All products bearing this symbol are waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) which should not be mixed with unsorted household waste. Instead, you should protect human health and the environment by handing over your waste equipment to a designated collection point for the recycling of waste electrical and electronic equipment, appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. Please contact the installer or local authorities for more information about the location as well as terms and conditions of such collection points.



Hereby, Tiinlab declares that the radio equipment type TWSEJ07WM is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:
<http://www.mi.com/global/service/support/declaration.html>

Safety Caution

- Do not expose batteries or battery packs to excessive heat such as sunshine, fire or the like.
- Replacement of a battery with an incorrect type that can defeat a safeguard (such as catching fire, explosion, leakage of corrosive electrolyte etc).
- Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
- Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
- A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- The product operation maximum ambient temperature is 40°C.



To prevent possible hearing damage, do not listen at high volume levels for long periods.



The symbol indicates DC voltage

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Xiaomi Inc. is under license. Other trademarks and trade names are those of their respective owners.

Manufactured for: Xiaomi Communications Co., Ltd.
Manufactured by: Tiinlab Acoustic Technology Limited
(a Mi Ecosystem company)

Address: Tianliao Building 1403, Tianliao Industrial Area A, Taoyuan Street, Nanshan District, Shenzhen 518055, China
For further information, please go to www.mi.com

Importer:
Beryko s.r.o.
Na Roudné 1162/76, 301 00 Plzeň
www.beryko.cz